

roll this down fuselage before glueing to a U-form

3 mm depron

3mm depron

deck and down side fuselage skin starts 8 cm from end

2x 3mm depron

position s4

side profile, one part

6mm depron

cut in two parts
glue upper part first on wings

10 cm

s4
6mm depron former

Summer 2005, www.parkjets.com

F-16C Falcon Parkjet (c) by Hans-Joachim Walter

missiles and all tanks are ending with the wing

cut later

position s2

position s1

position s3

wingplate

trim down to nose

s1

s2

s3